

Cash Cube Rules



1. Attendant(s) (at least 16 years of age) **must** be present at all times or the inflatable **must** be shut down.
2. The attendant(s) must enforce all rules and remove any rider who does not follow the rules and remove any rider who does not follow the rules.
3. Attendants and riders must not be under the influence of any mind-altering substances (drugs, alcohol, medications, etc) during operation.
4. Absolutely no rough play, tumbling, flipping, or diving allowed.
5. Remove all sharp objects, including jewelry.
6. No food, drink, or gum and **absolutely** no silly string. (Cleaning charges will be added)
7. No wet face paint
8. Do not operate unit in rain, lightning, darkness, or in winds exceeding 15mph.
9. If the unit begins to lose air, unload riders. Check your power source for a possible power problem.
10. Players must wear eye protection when inside the cash cube.
11. Paper should be crinkled so it moves freely within the machine and so it doesn't get stuck to the sides.
12. Turn the dial on the "Fun – Limiter" to adjust the timer.
13. Player should catch the pieces in mid-air, not against the sides or their body.
14. It is not recommended that you use real money.
- 15. Limitations:**
 - a. **Maximum Load: 1**
 - b. **Maximum Weight: n/a**
 - c. **Minimum Height: n/a**
 - d. **Minimum Recommended Age: n/a**
 - e. **Maximum Age: n/a**
16. Acme Partyworks recommends the use of whistles for all operators / supervisors to control this ride.
17. There are inherent risks in the participation in or on any amusement ride device or attraction. Patrons accept the risks inherent in such activity. Patrons have a duty to exercise good judgment and act in a responsible manner while using the equipment and to obey all oral and written warnings.

I have read and understand these rules. I will see that they are enforced.